

ROUND HANDRAIL POST CAP BRACKET

Model #275



Quick Install Instructions

QTY	ITEM
1	Post Cap Bracket – slides on top of Round Handrail Post
5	SS #12 x 1" Phillips Thin Head Self Drilling Screws – Predrill 3/16" hole through the cradle bracket into handrail. Install fastener and repeat for three other holes. Cradle piece can be removed if handrail impedes drill/screw gun
4	SS #10 x 1" Self drilling hex fasteners – attach bracket to post. Drill 3/16" pilot hole in more or more bracket dimples. Screw fastener in hole w/ hex head driver. <u>*** SEE ALTERNATIVE INSTALL METHODS BELOW</u>
2	7/16" Bolt caps – fits the bracket bolt and nut
2	1/2" Bolt caps – fits the 5/16" x 2-1/2 wood screws
1	3/16 Drill bit – Use to pilot 1" Self Drilling Fasteners.

	**Alternative Connection Pins for Post Cap to Post
6	1/8" x 3/4" roll pins – black – OPTIONAL: attach bracket to post. Using included bit, Drill 1/8" pilot hole in one or more bracket dimples. Carefully tap pin in hole with small hammer. Do not hit powder coat
	**Note: This is an alternative method for attaching the post cap to the post, pins or self-drillers, whichever you prefer. Pins will provide the cleanest most professional look and are a simple solution
	***Note: Construction adhesive or metal epoxy (not included) can be generously applied on the interior of the cap in the "adhesive trough" ring at the bottom in addition to or in place of mechanical fasteners.